

LAN

PC				LAN	
LaVieT	LT700/ 2D	PC- LT7002D	1 / 2002	WindowsXP	Fn+F2
	LT900/ 2D	PC- LT9002D			
	LT700/ 1D	PC- LT7001D	10 / 2001		
	LT900/ 1D	PC- LT9001D			
LaVieC	LC900/ 2D	PC- LC9002D	1 / 2002	WindowsXP	Fn+F2
	LC700/ 1D	PC- LC7001D	10 / 2001		
	LC900/ 1D	PC- LC9001D			
	LC900/ J 84DH	PC- LC900J 84DH	7 / 2001	ORINOCO Client Manager	
	LC900/ J 84DB	PC- LC900J 84DB			
LaVieJ	LJ 700/ 2D	PC- LJ 7002D	1 / 2002	WindowsXP	
LaVieG C LAN	LG10J S/A	PC- LG10J SFEA	1 / 2002	WindowsXP	Fn+F2
	LG10J S/9	PC- LG10J SFE9	10 / 2001		
	LG85J S/9	PC- LG85J SFE9			
	LG10J S/8	PC- LG10J SX58	7 / 2001	ORINOCO Client Manager	
	LG80J S/8	PC- LG80J SX58			
LaVieG T LAN	LG12J E/A	PC- LG12J EWEA	1 / 2002	WindowsXP	Fn+F2
	LG10J E/A	PC- LG10J EWEA			
	LG10J E/9	PC- LG10J EWE9	10 / 2001		
	LG85J E/9	PC- LG85J EWE9			
	LG10J E/8	PC- LG10J EV58	7 / 2001	ORINOCO Client Manager	
	LG80J E/8	PC- LG80J EV58			
LaVieG M LAN	LG85J V/A	PC- LG85J VHEA	1 / 2002	WindowsXP	
	LG85J V/9	PC- LG85J VHE9	10 / 2001		
	LG80HV/9	PC- LG80HVHE9			
LaVieG J LAN	LG65HJ / A	PC- LG65HJ HEA	1 / 2002	WindowsXP	
	LG65HJ / A- P	PC- LG65HJ HJ A			
	LG80J J / A	PC- LG80J J HEA			
	LG80J J / A- P	PC- LG80J J HJ A			
VersaPro LAN	VA80J / BH	PC- VA80J BH*E	1 / 2002	WindowsXP	
	VA65H/ BH	PC- VA65H BH*E			
VersaPro LAN	VA80J / BL	PC- VA80J BL*E	1 / 2002	WindowsXP	
	VA65H/ BL	PC- VA65H BL*E			
VersaPro LAN	VA80J / VH	PC- VA80J VH*E	10 / 2001	WindowsXP	Fn+F2
	VA60H/ VH	PC- VA60H VH*E		ORINOCO	
	VA70J / VH	PC- VA70J VH*D	7 / 2001	ORINOCO Client Manager	
VersaPro LAN	VA60H/ VH	PC- VA60H VH*D			
	VA86H/ DF	PC- VA86H DF*E	1 / 2002	WindowsXP	Fn+F2
	VA86H/ DX	PC- VA86H DX*E		ORINOCO	
	VA12J / DG	PC- VA12J DG*E	10 / 2001		
	VA11J / DF	PC- VA11J DF*E			
	VA10J / DF	PC- VA10J DF*E			
	VA86J / DF	PC- VA86J DF*E			
	VA80H/ DF	PC- VA80H DF*E			
	VA86J / DX	PC- VA86J DX*E			
	VA80H/ DX	PC- VA80H DX*E			
	VA11J / DF	PC- VA11J DF*D	7 / 2001	ORINOCO	
	VA10J / DF	PC- VA10J DF*D			

* : 1

LaVieG LAN
VersaPro LAN